# SafeCon<sup>®</sup> III - User manual hmk BILCON

•en sikker olieleverandør•også i fremtiden

16:16

22

EX I

R500

OLLERUP HOLLE ICS

SCAN

CN 91 182

1

MOLLERUP MOLLE

\*\*\*\*\*\*\*

# **Front-page**

### Hoses

Shows the different hoses, the size, and what product they contain. Can also be used to start a delivery.

### Flush

Rinse function to change product in a hose. The function is also found in a new window when a hose is selected.

#### Load

Load makes it possible to move product from the trailer to the truck.

	safe con	03/03 09:43 🗶 5	4
	1½"	Delivery history	Left
• 1	DIESEL F	1 - Receipt 6401B21D / 16466 Delivery	light
	2"	0L HV0 E 03/03/2023 09 38 53	light Right
	DIESEL F	2 - Receipt 6401B06A / 16465 Delivery	light ••••
2		0L HV0 03/03/2023 09:31:38	Rear light
		3 - Receipt 6400B41C / 16464 Delivery	Cabinet 6 • • •
		02/03/2023 153508	Cabinet light
		4 - Receipt 6400A3F1 / 16463	Trailer
2	Flush	203L HIVED 02/03/2023 1426:09	light
•••3	Load from trailer	Desctivate manual control	Warning light
	External	OL /7000L EMPTY PRINSSULE EXECT A 01 01 01 01 01 01 01 01 01 01 01 01 01	
		safe con	

#### Topbar / Menu

Menu where you can find TruckID and phone number for support. Warnings are also displayed in the top bar.

### **Delivery history**

Displays the deliveries made with SafeCon® III.

Lights

Turns the lights on and off.

#### Compartments

Compartments shows the content and quantity of product and can from the front-page be used to enter data and update product type / quantity. Compartments are used elsewhere to choose where to pump to and from.

# Manage your compartments

When you need to enter and update data in your compartments you must be on the front page. Once there, you can tap the compartment you want to enter and then the screen on the right will appear.

From here, all you have to do is enter the volume and product you want to put into the compartment. This is done through the Numpad <sup>1</sup> and then you select the product by tapping one of the specified products <sup>2</sup>. Finish the entry by pressing 'Confirm'.

The number of products can vary from truck to truck. It is possible to get categorized products in tabs as well as get a tailored product list.



# How to set up a delivery

### Quickguide

Select hose → Select compartment→ Confirm → Start the pump "▶"

To enter order setup select either a hose from the front page or press the 'Manual order' button. If the order setup is started by selecting a hose, the hose is selected in advance.

Before a delivery can be started, the only requirement is that you choose which compartment you want to deliver from. A compartment is selected by tapping it at the bottom of the screen which also sets the product type automatically.

If you want to deliver a certain volume you can press Preset <sup>1</sup> and set how many liters are to be delivered.

If more than one compartment is selected, the Delivery Method <sup>2</sup> button can be used to decide whether the compartments should open simultaneously (in parallel) or whether they should be opened one by one (sequentially). If sequential is selected the first compartment will be opened during delivery and when the compartment is empty the next compartment in the row will be opened.

Further options include setting the engine speed <sup>3</sup> and pressure <sup>4</sup> as well as decide whether the Drag brake <sup>5</sup> and Start-up Assistance <sup>6</sup> should be active or not. Finally, you can choose whether a printed receipt <sup>7</sup> is required or not.





SafeCon® III

### Flush Setup

safe CON	03/03 09:53	*			
1½"		F	lush		Left light
DIESEL		1		Low	iigiit
2"	Hose	Source	Delivery method Sequential	0.0 Bar	Right
DIESEL	Internal		00-00. • 00-00 00-00	- +	light
	Flush volu	<sup>ime</sup> 2			Rear
	90L		Target		light
	DIESEL	F DESEL	F DESEL F		Cabinet
	Manifold (SOL)	Delivery (10L)	Ext: manifold (1L)	Start-up	light
Flush				assistance	Trailer
Flush					light
					Warning
Load from trailer Receipt			Cancel Co	onfirm	light
		OL	<sup>5</sup> 2000L <sup>4</sup> 4000L	<sup>3</sup> 4500L <sup>2</sup> 4500	u <sup>1</sup>
			IL /4500L /4500L	/4500L /4500	
			FYRINGSOLJE HVO FARGET FARGET	BLYFRI 95 BLYFRI 9 BENSIN BENSIN	

### Quickguide

Select Flush  $\rightarrow$  Select hose  $\rightarrow$  Select source compartment  $\rightarrow$  Select target  $\rightarrow$  Select target compartment  $\rightarrow$  Confirm

You can access Flush by selecting the function on the front-page or select a hose and then select Flush. The flush volume is set according to the hose but can be changed manually.

The way you select compartments is to select Source 1 and select compartment at the bottom. Then press Target 2 and select the compartment you want to flush to.

# **Load Setup**



### Quickguide


Select Load from Trailer  $\rightarrow$  Select product to load  $\rightarrow$  Select target compartment  $\rightarrow$  Confirm

You can access Load from Trailer by selecting the function on the frontpage. There may be a difference in how Load from Trailer works depending on how your truck is built.

When you Load from Trailer, you specify the product 1 you're going to pump and then the compartment(s) you want to load into 2. You can load into one or more compartments, but if several compartments are selected, they will open simultaneously (in parallel).

### SafeCon® III

### **Remotes**



The remote control may differ from truck to truck, and the above is indicative. All functions shown on the remote control, which are written in **WHITE**, are done by simply pressing the button. All functions written in **GREEN** are done by first pressing the FN, and then the function you want.



# Call our online support

At HMK Bilcon, we put emphasis on our service being top notch. We know time is money so we do our utmost to make sure you keep running.

We do however acknowledge that problems occur. Call us if you experience any issues with your truck.

# +45 92721761

HMK Bilcon A/S | Hadsundvej 295 | 9260 Gistrup | Denmark | +45 98 32 30 11 | www.hmkbilcon.com